

INSTALLING SLATWALL PANELS

Panels can be attached to finished or unfinished walls using appropriate screws and, in the case of dry wall, plastic anchors.

A few basic points:

- Level all panels — level bottom panel first.
- Screws should always be through the “slots”, never through the “slats” and should be countersunk (this allows smooth insertion of slatwall fixtures and hardware). Flathead screws work best.
- When panels are attached to wall studs or furring strips, studs/strips should be no less than 16” on center.
- Construction adhesive may be used in addition to screws, to form more secure bond

COUNTERSINK ALL SCREWS TO ENSURE PROPER FIT OF SLATWALL FIXTURES & ACCESSORIES

