


ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE




ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE


PARTS IN CARTON:




CAM LOCK PINS
(21 EACH)




SUPPORT FOOT
(3 EACH)




SUPPORT CAP
(3 EACH)



16' FOAM TAPE
(1 EACH)




FOAM GLAZING
(28 EACH)



METAL SHELF
BRACKETS (6 EACH)



PAN HEAD
SCREW
(12 EACH)




SHELF REST
& BUMPER
(12 / 24 EACH)



CORNER CAP
(4 EACH)




1" FLATHEAD
SCREW
(3 EACH)



GLASS
SUPPORTS
(4 EACH)



STANDARD
(3 EACH)



DOOR TRACK
INSERTS
(2 EACH)

DOWN
TUBE CAP
(1 EACH)


ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE


PARTS IN CARTON:




MIDDLE SUPPORT
(1 EACH)




FRONT / BACK PANEL
(2 EACH)




SIDE PANEL
(2 EACH)






BOTTOM DECK FRAME
(1 EACH)



TOP DECK FRAME
(1 EACH)



DOOR PANEL
(2 EACH)



GLASS PANELS (SIDES, TOP, FRONT, BACK)


YOU WILL NEED TO SUPPLY YOUR OWN DRILL OR SCREWDRIVER & RUBBER Mallet FOR INSTALLATION.

ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE


STEP 1

INSERT CAM LOCK PINS INTO EACH PANEL.
(USING A MANUAL SCREW DRIVER IS BEST,
TO HELP AVOID OVER TIGHTENING.)



STEP 2

ENSURE EACH PRE-INSERTED CAM IS
ORIENTED SO THE CAM ARROW IS FACING
THE CORRESPONDING HOLE.




ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE

STEP 3

PLACE EACH FRONT & BACK PANEL ONTO THE MIDDLE SUPPORT CAM PINS.
(TIGHTEN CAMS)




ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE


STEP 4

CAREFULLY LOWER THE SIDE ASSEMBLY ONTO THE BOTTOM DECK.
(TIGHTEN CAMS)



STEP 5

INSERT EACH SIDE PANEL PINS INTO THE CAM LOCK HOLES.
(TIGHTEN CAMS)




ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE


STEP 6

USING A RUBBER MALLET, INSERT EACH
CORNER CAP ONTO THE KICK
PLATE CORNERS.



STEP 7

ROTATE THE BOTTOM DECK.
PLACE THE FOAM GLAZING &
DOOR TRACK INSERTS
INTO PLACE.




ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE


STEP 8

PLACE THE CORRESPONDING GLASS SUPPORTS ONTO EACH MATCHING CORNER.




STEP 9

PLACE THE GLASS PANELS CAREFULLY INTO THE GROOVES OF THE SUPPORTS & SLOWLY PRESS INTO PLACE.



STEP 10

PLACE THE FOAM GLAZING ONTO THE TOP DECK FRAME.




ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE

STEP 11

CAREFULLY PLACE THE TOP DECK
FRAME ONTO THE ASSEMBLY,
SLIDING THE PEGS INTO THE
CORRESPONDING GLASS
FRAME SUPPORTS.




ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE

STEP 12

ADD SCREWS TO EACH GLASS SUPPORT CORNER (SEE FIGURE 1). PLACE LOWER UPRIGHT FOOT INTO POSITION & SECURE INTO PLACE (SEE FIGURE 2). FINALLY, INSERT THE UPRIGHT AND SECURE INTO PLACE WITH #8 SCREW, SECURE UPRIGHT CAP INTO PLACE. (SEE FIGURE 3).




ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE

STEP 13

PLACE FOAM ADHESIVE STRIPS ONTO THE TOP METAL GLASS SUPPORT, CUT ON A 45° ANGLE, THEN CAREFULLY LOWER THE GLASS INTO PLACE. FINALLY, SET DOORS INTO THEIR TRACKS AND SLIDE INTO FINAL POSITION.





ASSEMBLY INSTRUCTIONS MANUAL

65246 - EXTRA VISION METAL FRAMED BLACK DISPLAY CASE

STEP 14

ASSEMBLE EACH SHELF REST BY INSERTING A SHELF BUMPER INTO THE SHELF REST HOLES.



STEP 15

PLACE EACH SHELF REST ON TO THE SHELF BRACKETS. CENTER EACH REST ABOVE EACH BRACKET HOLE.

STEP 16

FINALLY PLACE EACH SHELF ONTO THE SHELF BRACKETS. **NOTE: TAKE CARE NOT TO HIT OR DROP THE GLASS SHELVES. RECENTER SHELVES AS NEEDED. IT IS IMPORTANT TO HAVE THE SHELVES CENTERED TO AVOID TIPPING WHEN SHELVES ARE LOADED WITH PRODUCT.**

