
#60-261 29 BALL SPIRAL RACK



9801 PAGE AVENUE ST. LOUIS, MO. 63132-1428

TEL: (314) 427-8887

or (800) 823-8887

FAX: (314) 427-0004

or (800) 823-0004

Final: 9/24/10



PAGE 1 of 5

60-261 ASSEMBLY INSTRUCTION 29 BALL SPIRAL RACK PARTS IN CARTON: SPIRAL HANGROD 1 EACH 18" DIA. BASE PLATE 1 EACH ARM BRACKETS WITH COLLAR 2 EACH NOTE: WRENCH IS TAPED TO THE INSIDE BOTTOM OF BASE PLATE. TOOL INCLUDED (NOT ACTUAL SIZE) (SMALL) 1/8 INCH

UPPER POLE

WITH TAPERED

END

1 EACH

LOWER POLE WITH LOCKING

COLLAR

1 EACH

ALLEN WRENCH



PAGE 2 of 5


60-261 ASSEMBLY INSTRUCTION 29 BALL SPIRAL RACK

ASSEMBLY STEPS:


STEP 1

SCREW THE THREADED END OF LOWER POLE INTO THE 18" DIA. BASE PLATE BY HAND UNTIL COLLAR IS TIGHT AGAINST BASE PLATE.

(SEE FIG. 1 AND 1A)



UNIT SHOULD NOW LOOK LIKE THIS






PAGE 3 of 5


60-261 ASSEMBLY INSTRUCTION 29 BALL SPIRAL RACK

ASSEMBLY STEPS CONTINUES:



60-261 ASSEMBLY INSTRUCTION 29 BALL SPIRAL RACK

ASSEMBLY STEPS CONTINUES:



STEP 3

SLIDE THE TAPERED END OF THE POLE ON THE ASSEMBLED SPIRAL HANGROD SECTION FROM STEP 2 INTO THE LOWER POLE OF THE BASE SECTION AS SHOWN TO THE LEFT.

ADJUSMENT NOTE:

ADJUSMENT OF SPIRAL HANGROD CAN BE ACHEIVED BY LOOSENING THE SET SCREW ON LOWER COLLAR. THEN BY HOLDING ONTO THE UPPER ARM AND COLLAR LOOSEN THE TOP SET SCREW AND SLIDE UP OR DOWN FOR YOUR FINAL ADJUSTMENT.

UNIT IS COMPLETE
SEE COVER FOR ASSEMBLED FIXTURE



PAGE 5 of 5