

# Store Supply Warehouse

## Economy Aisle Gondola Assembly Instructions

Recommended Two Person Assembly    Average Assembly Time 20 Minutes

- 1- Remove the cap from the bottom of the **UPRIGHT STANDARDS** and insert a **BASE FOOT** into each of the **UPRIGHT STANDARDS**. Replace bottom cap.
- 2- Attach the **BASE KICKPLATE** into the slots in each **BASE FOOT**.
- 3- Lower the **BASE SHELF** in place by lining up the edge of the shelf with the grooves in the **BASE FOOT**.
- 4- Insert the **7" PEGBOARD BACKERS** into the slots on the inner bottom of the **UPRIGHT STANDARDS**. Repeat this process for each of the **12" PEGBOARD BACKERS**.
- 5- Place the **METAL TOP SPANNER** in place on top of the unit to complete the installation.

### Parts List

- Upright Standard (2)
- Base Foot (4)
- Base Kickplate (2)
- Base Shelf (2)
- 7" Pegboard Backer (2)
- 12" Pegboard Backer (8)
- Metal Top Spanner (1)

