





STANDING GRID SCREEN/GRID LEGS ASSEMBLY INSTRUCTIONS

GRID LEGS



- PARTS:
2- Legs
4- Bolts
4- Nuts
8- Lock Washers



NOTE: Grid Panel Has Double Wires on long-sides -- the grid-leg's bolts fit between these wires and attach to nut on inside of panel.

