



# METAL FRAMED SERVICE COUNTER

## RECOMMENDED TOOLS FOR ASSEMBLY

---



PHILLIPS SCREW DRIVER




RUBBER Mallet

## HARDWARE AND MISC. INCLUDED: (PACKAGED IN A BAG)




CAM LOCK PINS-1 3/4" L



3/4 CAM LOCK


CONNECTOR NUTS (CAM LOCKS MAY  
ALREADY BE INSERTED INTO PANELS)



PAN HEAD SCREWS- 5/8" L



STEEL FLAT HEAD SCREWS-1 1/4"  
L



STEEL FLAT HEAD SCREWS  
1" L

# METAL FRAMED SERVICE COUNTER

## ASSEMBLING BOTTOM BASE

### STEP 1:

Insert cam locks into bottom base, Place front and back bottom base panels onto bottom base, SEE DIAGRAM 1, Tighten inside cam locks, Next insert cam locks into bottom base side panels, Then place on the sides of the bottom base, SEE DIAGRAM 2, Attached end caps flush to the base corners.

BOTTOM BASE WITH CAM  
LOCKS INSERTED

SIDE PANEL WITH CAM  
LOCKS INSERTED



BASE CORNER END CAPS



DIAGRAM 1




DIAGRAM 2



# METAL FRAMED SERVICE COUNTER

## ATTACHING FRONT PANEL AND MIDDLE SHELF

---

### STEP 2:

Insert cam locks into front panel, Next place front panel onto bottom base cam locks, SEE DIAGRAM 1, Tighten cams on inside of bottom base.

FRONT PANEL




DIAGRAM 1



DIAGRAM 2



### STEP 3:

Place middle shelf onto center cam locks on front panel as shown in DIAGRAM 2, Tighten cam locks insert in middle shelf panel.

# METAL FRAMED SERVICE COUNTER

## APPLYING SUPPORT BAR AND SIDE PANEL

---

### STEP 4:

Insert wooden dowels into support bar, Place support between bottom base and middle shelf as shown in DIAGRAM 1.

SUPPORT PANEL




DIAGRAM 1



### STEP 5:

Place cam locks in other side panel, Then place the side panel onto the side of the counter, with holes in the top of the panel, as shown in DIAGRAM 2. Place end caps on back end corners flush using rubber mallet, Tighten bottom corner cam locks and top inside cam locks





# METAL FRAMED SERVICE COUNTER

## INSTALLING TOP PANEL

---

### STEP 6:

Insert cam locks into top of counter, Then place top onto counter cam locks will insert into holes on the frame, Tighten cam locks on inside. Make sure to include hardware bag that comes inside box and the shelf separators that come in the box.

### TOP PANEL



# METAL FRAMED SERVICE COUNTER

FINALIZED SERVICE COUNTER

---

FRONT OF COUNTER



BACK OF COUNTER

